

# CONSEVV 733R

Operator's Guide




#### **HOW TO SET HANDWHEEL**


Remove two screws and take off bushing, and set handwheel with the two screws.



#### **LUBRICATION**


Use white spindle oil. When starting the machine initially and after kept for a long time without using at all, oil sufficiently to respective necessary parts before starting operation, pre-running and with severe use. Oil frequently each necessary parts during operation.






#### HOW TO SET THE NEEDLE

- \* Move needle bar to HIGHEST point. Loosen needle set screw.
- \* Insert needle up as far as possible, setting its long groove towards the left.
- Tighten needle set screw securely.





#### WINDING THE BOBBIN


- \* Set bobbin winder as shown
- B: Adjustment of center position
- C: Adjustment of winding amount




#### INSERTING & REMOVING THE BOBBIN









#### THREADING NEEDLE








#### -THREAD TENSIONS-

## ADJUSTMENT OF FOOT PRESSURE











MORE TENSION . . . turn to right
LESS TENSION . . . turn to left
SUITABLE TENSION . . . determined by type of material being sewn

### ADJUSTMENT OF STITCH LENGTH




Adjust Stitch length by serrated nut (A) and tighten nut (B) against nut (A)

# ADJUSTMENT OF ALTERNATING PRESSER AND UPPER FEED



C . . . adjustment of alternating presser

D... adjustment of feeding amount of outer foot





### CONSOLIDATED SEWING MACHINE CORP.

1115 Broadway, New York, N.Y. 10010 U.S.A.

OFFICE IN Los Angeles: 2401 South Broadway, Los Angeles, Calif., 90007 U.S.A. Osaka, Japan: CONSEW INTERNATIONAL LIMITED

Yamajin Bldg., 18, 1-chome, Hon-machi, Higashi-ku, Osaka, Japan